DEC-VT05-IPB-1

ILLUSTRATED PARTS BREAKDOWN

VTO5 ALPHANUMERIC DISPLAY TERMINAL

HOW TO USE THE IPB

GENERAL

This IPB is compiled following the organization and nomenclature of the engineering drawing structure.

MAJOR ASSEMBLY LOCATOR

The Major Assembly Locator (first illustration) is an index that provides a description and a figure reference for all illustrations used in this manual.

INDENTED PARTS LIST

This manual identifies each assembly being broken down (figure reference callout), and all parts of that assembly. Further breakdown of an assembly is shown by an asterisk (*) preceding the item callouts in the Description Column. The number of asterisks preceding an item is used to denote the subordination of that item with respect to the Major Assembly. A single asterisk preceding an item description indicates that the item is part of the major assembly being illustrated. Items that are subordinate to single asterisks items, are denoted by two asterisks (**) and immediately follow the related single asterisk item. Additional asterisks are used, as required, to denote further subordination. This system of part identification, provides a means for the user to identify the next higher assembly item and make alternate selections for parts when the required replacement part or assembly is not immediately available.

COLUMN CALLOUT DESCRIPTION

Figure & Item — Indicates the figure number and item number of each part.

Description — Lists the name of the part and pertinent specifications (when required). Asterisks preceding the description denote the subordination of the part to the next higher assembly.

DEC Part No. — Lists the DEC part ordering number. A blank in this column indicates a DEC part number was not assigned at the time of publication.

ECO Cut-In — The notation at the top of this column indicates the ECO level of the system (option), at which the IPB was initially prepared. Subsequent ECO level designations, that modify existing parts or add new parts to the device, are inserted in the ECO Cut-In column next to the part that is added or modified. A bracket ([) preceding the item description is used to indicate the parts affected by ECO's.

Vendor Code/Part No. — Indicates vendor parts that are not stocked by DEC. Refer to the Field Service Spares Catalog (vendor part number to DEC part number) for the vendor code cross-reference.

Used On Code — Letters in this column correspond to the variation codes assigned in Figure 1. Parts with an Alpha notation(s) are used only in those option variations. A blank indicates that the part is used on all option variations.

Ref Fig No. — A cross reference between illustrations. For each Major Assembly, the number in this column denotes the figure of the next higher assembly. For all subassemblies, the number in this column denotes the figure showing additional detailed breakdown.

SYMBOL USAGE

Hardware Designators — Alpha designators for screws (S), washers (W), nuts (N), and retaining rings (R) are inserted after the item number callouts on the illustration when stacked item numbers are used.

Attaching Hardware — The @ symbol is inserted before any part that is used as attaching hardware. Attaching hardware is denoted as those parts that are not an integral part of the referenced assembly.

(NFR) Not Field Repairable — The (NFR) symbol is inserted after any assembly that is not to be field dismantled.

Other Symbols – Any other symbols that are required for kits, accessories, etc., will be explained and appear as part of the item description.

REVISION HISTORY

		8 8 000	VIOLOIT IIIOI		
PRINTING	ECO LEVEL	DATE		PAGES AFFECTED	
1st Printing 1st Printing	VT05 00015-00066 54-09945-00003-00003	5-14-73	N/A N/A		
,					
		1			


Copyright © 1973, by Digital Equipment Corporation

DEC reserves the right, without notice, to make substitutions and modifications in the specifications of products documented in this manual and further reserves the right to withdraw any of these products from the market without notice.

DEC is not responsible for errors which may appear in the technical description (including illustrations and photographs) of the products covered by this manual.

None of the descriptions contained in this manual imply the granting of any license whatsoever to make, use or sell equipment constructed in accordance therewith.

÷ in. , is



Major Assembly Locator, VT05 Alphanumeric Display Terminal

		in the second se
		· ·
		w
		ir No




Figure 1. VT05 Alphanumeric Display Terminal

FIG &		DEO	ECO CUT-IN	LICED ON		VENDOR	REF	Eliberatura de la companya de la com
ITEM NO.	DESCRIPTION	DEC PART NO.	VT05 00015	USED ON CODE	CODE	PART NO.	FIG NO.	Odnica de la constante de la c
1-	VT05 ALPHANUMERIC DISPLAY	VT05-00						OCCUPATION OF THE PERSON OF TH
1	TERMINAL ASSEMBLY *Base, Plastic	10 10010 00						
2	*Screen, Protective	12-10913-00 74-08891-00						
3	*SCOPE ASSEMBLY	30-10326-00						
4	*Screw, Phi Pan Hd No. 10-32 x .62 Lg	90-06074-01						
5	*Washer, Lock No. 10 Int. Tooth	90-06636-00						
6	*Speaker, 16 Ohm, 1/4W	12-10299-00						
7	*LK01 KEYBOARD ASSEMBLY (128 Characters	1					4	
8 9	*Bracket, Large Keyboard (R.H.)	74-08638-01						
10	*Bracket, Large Keyboard (L.H.) *Screw, PhI Pan Hd No. 8-32 x .50 Lg	74-08638-02 90-06039-01						ĺ
11	*Washer, Lock No. 8 Int Tooth	90-06634-01						at District
12	*Plate, Shim (Large Keyboard)(added)	74-10760-00	00063					- Allegar
13	*Screw, PhI Pan Hd No. 8-32 x .62 Lg	90-06040-01						
14	*CURSOR BOARD ASSEMBLY (8 Keys)	54-10224-00	an comment				5	
15 16	*Screw, Phi Pan Hd No. 4-40 x .38 Lg *Washer, Lock No. 4 Int Tooth	90-06011-01						
17	*Button, Rocker Switch (ON-OFF)	90-06632-00 12-10348-00						
18	*Button, Rocker Switch (LOC-REM)	12-10348-00					Distriction	
19	*Bracket, Small Keyboard	74-08852-00						- Description
20	*Screw, Phi Pan Hd No. 4-40 x .25 Lg	90-08301-01						
21	*Screw, Phi Pan Hd No. 4-40 x .31 Lg	90-06010-01						
22 23	*Nut, Kep No. 4-40 Hex *Plate, Shim, (Small Keyboard)(added)	90-06557-00	00000					
24	*Cable, Keyboard Interconnecting (added)	74-10759-00 70-08612-00	00063 00038					
25	*POT ASSEMBLY	70-03012-00	00038		and the same of th		3	
26	*Screw, PhI Pan Hd No. 6-32 x .50 Lg	90-06024-01						
27	*Nut, Kep No. 6-32 Hex	90-06560-00						
28	*Bracket, Mtg Switch	74-08894-00						
29 30	*Screw, PhI Pan Hd No. 6-32 x .38 Lg *Washer, Lock No. 6 Int Tooth	90-06022-01						1
31	*Insulator	90-06633-00 74-09285-00	00038					ĺ
32	*Screw, Nylon No. 6-32 x 1/4	90-09041-02	00038					
33	*H733 POWER SUPPLY ASSEMBLY	H733-00						
34	*POWER SUPPLY JUMPER ASSEMBLY	70-08425-01						
35	*Fan (Obsolete) *Fan	12-0533-02						
36	*Screen, Fan	12-09942-01 74-04881-00	00048					
37	*Screw, Fill Hd No. 8-32 x .38 Lg	90-06121-00						
38	*Capacitor 2 x .1 MFD 1000 VDC	10-00034-00						
39	*Nut, Speed Tinn	90-06584-00						
40	*Retainer, Connector Block	74-08580-01						
41 42	*Retainer, Connector Block *BUS BOARD (VT05)	74-08580-02						
43	*CURSOR CONTROL MODULE	E020-00 M7000-00						
44	*CHARACTER GENERATOR and TIMING	M7001-00						ONE
	MODULE	na.					and the same of th	Mary Commercial Commer
45 46	*MEMORY and MEMORY TIMING MODULE	M7002-00						
46 47	*INTERFACE MODULE (VT05A ONLY) *INTERFACE MODULE (VT05B ONLY)	M7003-00						-
48	*Holder, Module	M7004-00 12-09856-01						- September - Sept
49	*Clamp, Cable Nylon 3/8	90-07083-00			P920-00545			- Parties
50	*HARNESS and BACK PLATE ASSEMBLY	70-07231-00					2	
51 50	*Cord, Power	70-08502-09						Eggloue
52 53	*Cover, Rework	74-08900-00						-
53 54	*Shield, Scope *Mask, Scope	74-08585-00 12-10479-00			O. C.			House
55	*Washer, Nylon No. 8	90-06708-00			ANTHONIO COSTONICO			
	ACCESSORY LIST	AUTODOS GALLANTE	AN POSTALE PARTIES AND THE PAR					
	tMachar Nivion (Essa)	40 40504 50						1
	†Washer, Nylon (Feet) †Screw, Nylon (Feet)	12-10581-00 12-10852-00						Management
	†Interface Cable	70-08519-00	00031					
		1 2 2 2 7 3 3 3 3	1					
			100					
L		L	1				Ĭ.	ı




Figure 2. Harness and Backplate Assembly

5

FIG & ITEM NO.	DESCRIPTION	DEC PART NO.	ECO CUT-IN VT05 00015	USED ON CODE	CODE	VENDOR PART NO.	REF FIG NO.	g
& ITEM	DESCRIPTION HARNESS and BACK PLATE ASSEMBLY *Back Plate *Switch, Rotary (S1)(obsolete) *Switch, Rotary (S1) *Knob *Connector, BNC (P1, P2, P3, P4) *Ground, Terminal BNC *Switch, Side (S2, S3) *Nut, Kep No. 4-40 *Plug, Cinch Jones (P5) *Screw, PhI Pan Hd No. 4-40 x .25 Lg *Washer, Lock Int Tooth No. 4 *Screw PhI Pan Hd No. 6-32 x .31 Lg (Used for fastening Item 20 to Back Plate Item 1) *Washer, Lock Int Tooth No. 6 (Used for fastening Item 20 to Back Plate Item 1) *Strip, Terminal (TB1) Cinch Jones 6-140 *Nut, Kep No. 6-32 *Circuit Breaker (CB1) *Bushing, Snap SB875-6 *Switch, Slide (S4, S5) *Switch, Interlock (S6) *POWER HARNESS ASSEMBLY **Connector (P8) Mate-N-Lok **Connector (P9) Mate-N-Lok (Obsolete—Used on Datanetics Keyboard only) **Housing (P2, P6) No. 20283 Berg **Plug-Cord **Connector (P4) Mate-N-Lok **Connector (P3, P7) Mate-N-Lok **Connector (P3, P7) Mate-N-Lok **Connector (P1) Mate-N-Lok	N .	CUT-IN VT05)		á	FIG	g

FIG & ITEM NO.	DESCRIPTION	DEC PART NO.	ECO CUT-IN VT05 00015	USED ON CODE	CODE	/ENDOR PART NO.	REF FIG NO.
3	POT ASSEMBLY *Bracket, Pot Mounting *Pot, (R3, R4) 10K 2W 10% *Pot, (R2) 1K 2W 10% *Pot, (R1) 250K 2W 10% *Knob, 1 in. Dia. *Screw, Soc Hd Set No. 6-32 x 1/4 Lg *Connector, Mate-N-Lok *Pin, Connector *Wrap, Tie (Panduit)	70-07232-00 74-08564-00 13-02205-00 13-00370-00 13-10311-00 12-10227-00 90-06291-10 12-09378-01 90-07031-00					1




Figure 3. Pot Assembly

			e.
			· **
			\$




Figure 4. LK01 Keyboard Assembly (Sheet 1 of 2)

9




Figure 4. LK01 Keyboard Assembly (Sheet 2 of 2)

FIG & ITEM NO.	DESCRIPTION	DEC	ECO CUT-IN 54-09945	USED ON		VENDOR	REF FIG	
110.	DESCRIPTION	PART NO.	00003	CODE	CODE	PART NO.	NO.	
4—								
57	**Key Cap, Single A	90-09148-01			53500000000000000000000000000000000000	NO.		
58	**Key Cap, Single B	90-09148-01						and the same of th
59	**Key Cap, Single C	90-09148-03						
60	**Key Cap, Single D	90-09148-04						
61	**Key Cap, Single E	90-09148-05						altorellassic
62	**Key Cap, Single F	90-09148-06				s and a second		
63	**Key Cap, Single G	90-09148-07						
64	**Key Cap, Single H	90-09148-08						
65	**Key Cap, Single I	90-09148-09						
66 67	**Key Cap, Single J	90-09148-10						
68	**Key Cap, Single K **Key Cap, Single L	90-09148-11						
69	**Key Cap, Single M	90-09148-12 90-09148-13						STORY OF THE PERSONS
70	**Key Cap, Single N	90-09148-13						
71	**Key Cap, Single O	90-09148-15						
72	**Key Cap, Single P	90-09148-16	CO CONTROL OF THE CON				Koma	
73	**Key Cap, Single Q	90-09148-17						
74	**Key Cap, Single R	90-09148-18						
75 76	**Key Cap, Single S	90-09148-19						
76	**Key Cap, Single T **Key Cap, Single U	90-09148-20						
78	**Key Cap, Single V	90-09148-21	A DECEMBER	200				
79	**Key Cap, Single W	90-09148-22 90-09148-23						
80	**Key Cap, Single X	90-09148-24		0				
81	**Key Cap, Single Y	90-09148-25						
82	**Key Cap, Single Z	90-09148-26						
83 84	**Key Cap, Single {	90-09148-27						
85	**Key Cap, Single ! 1 **Key Cap, Single '' 2	90-09148-28						
86	**Key Cap, Single '' 2 **Key Cap, Single # 3	90-09148-29 90-09148-30					1	
87	**Key Cap, Single \$ 4	90-09148-31					4	
88	**Key Cap, Single % 5	90-09148-32	THE STATE OF THE S				-	- 3
89	**Key Cap, Single & 6	90-09148-33					STATE OF THE PERSON NAMED IN	
90	**Key Cap, Single '7	90-09148-34						
91	**Key Cap, Single (8	90-09148-35						
92 93	**Key Cap, Single) 9	90-09148-36						
93	**Key Cap, Single 0 **Key Cap, Single = -	90-09148-37						
95	**Key Cap, Single	90-09148-38 90-09148-39						
96	**Key Cap, Single }]	90-09148-40	Chromese Chromese					
97	**Key Cap, Single CR	90-09148-41	No.					
98	**Key Cap, Single LF	90-09148-42						
99	**Key Cap, Single \ @	90-09148-43						
100 101	**Key Cap, Single ALT	90-09148-44	NAME OF THE OWNER OWNER OF THE OWNER OWNER OF THE OWNER OWNE					
101	**Key Cap, Single TAB **Key Cap, Single CTRL	90-09148-45					paragraph (
103	**Key Cap, Single ~ A	90-09148-46 90-09148-47		RINGS COO			No.	
104	**Key Cap, Single + ;	90-09148-48						
105	**Key Cap, Single * :	90-09148-49		the control of the co				
106	**Key Cap, Single RUB OUT	90-09148-50						
107	**Key Cap, Single \	90-09148-51						
108 109	**Key Cap, Single SHIFT	90-09148-52						
109	**Key Cap, Single ? / **Key Cap, Single > .	90-09148-53						
111	**Key Cap, Single > . **Key Cap, Single < ,	90-09148-54 90-09148-55						
112	*Cover, Dust (R.H.)	74-09514-00						
113	*Cover, Dust (L.H.)	74-09514-00						
114	*Screw, SI Binder Hd No. 2-56 x 5/16 Lg	90-06002-04					To the same of the	
							Management	
					DO COMPANY			
								1
								*
					and the same			
					l l		e h	

FIG &		DEC	ECO CUT-IN VT05	USED ON	\	/ENDOR	REF FIG
NO.	DESCRIPTION	PART NO.	00015	CODE	CODE	PART NO.	NO.
NU. 5- 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23	CURSOR KEYBOARD ASSEMBLY *Board, P.C. Cursor *Resistor, 68K %W 5% (Carbon Comp) *Capacitor, .005 UF *Transistor, NPN *Socket, 16 Pin IC *Standoff, Channel *Screw, No. 2-56 x 5/16 Lg *Washer, Nylon *Channel, Machining *Guide, Key *Shaft, Stepped 90° Turn Key *Plate, Coupling *Screw, Drive 3/16 *Spring, Light *KEYCAP, SINGLE (Complete set — 8 Keycaps) *Keycap, Single HOME *Keycap, Single EOS *Keycap, Single EOL *Keycap, Single → ↑ ↓ *Cover, Dust *Screw, No. 2-56 x 1/4 Lg	54-10224-00 50-10223-00 13-01327-00 10-01765-00 15-10948-00 12-10025-00 74-09538-00 90-06031-00 90-09263-00 74-10520-00 74-09525-00 74-10549-00 74-09516-00 90-09162-00 90-09148-63 90-09148-63 90-09148-61 90-09148-61 90-09148-61 90-09148-61 90-09148-61 90-09148-61 90-09148-61					1




Figure 5. Cursor Keyboard Assembly

ILLUSTRATED PARTS BREAKDOWN COMMENT SHEET

Any and all comments and suggestions for correcting errors and/or additional information to improve this manual will be reviewed and researched for possible use when this manual is revised and/or reprinted. Enter your comments and suggestions in the form provided below and return to Technical Documentation.

MODEL		PUBLICATION NO	
FIGURE NO.	ITEM NO	FIGURE NO.	ITEM NO
CHANGE FROM		CHANGE FROM	
CHANGE TO		CHANGE TO	
FIGURE NO.	ITEM NO	FIGURE NO.	ITEM NO
CHANGE FROM		CHANGE FROM	
CHANGE TO		CHANGE TO	
FIGURE NO.	_ ITEM NO	FIGURE NO	ITEM NO
CHANGE FROM		CHANGE FROM	
CHANGE TO		CHANGE TO	
ADDITIONAL COMMENT(S	5)		
Nome			
Name			
Cost Center			
date:			

-		
	Fold Here	
	7 old Here	
	— Do Not Tear - Fold Here and Staple — —	
		FIRST CLASS PERMIT NO. 33 MAYNARD, MASS.
BUSINESS REPLY MAIL NO POSTAGE STAMP NEC	ESSARY IF MAILED IN THE UNITED STATES	
Postage will be paid by:		
	Digital Equipment Corporation Technical Documentation Department	
	146 Main Street Maynard, Massachusetts 01754	
	• ,	